




KNOB



LEVER




CARE AND MAINTENANCE

THE FOLLOWING CARE INSTRUCTIONS SHOULD BE FOLLOWED TO ENSURE A LONG LASTING FINISH:


1. Remove locks, or do not install locks, prior to painting your door.
2. Periodically clean with mild soap and a soft cloth only.

Do not use abrasives or harsh chemicals, and avoid sharp or scratching objects.

LHR



RHR



EXTERIOR

DOOR FACE



Backset
2-3/8 in. (60mm)

Backset 2-3/4 in. (70mm)

